grazia&co melbourne 1/10-14 advantage road highett, vic, 3190 phone 03 9555 5760

grazia&co sydney 12b, 32 ralph street alexandria, nsw, 2015 phone 02 8914 0350

prince side table



australian made 20mm thick round solid american oak top with soft rounded sharknose edge detail sitting on single bean shaped pedestal base. low and tall sold separately or as a duo.




timber





technical **specifications**





product specifications

designer iva foscia for grazia&co

design registration no 202013031

year designed 2020

warranty

i. warranty period of 2 years for the structural integrity of the furniture under 'normal use'

ii. natural materials like solid and veneer timbers can vary in colour, natural figuration and texture. these are not considered faults.iii. movement, joint separation, bowing as a result of fluctuations in temperature and any damage caused by direct sunlight are not warranted.

iv. day to day use and wear and tear that can cause scratches,expansion, colour changes, chips, burns, splits are not warranted.v. painted and stained timber can chip. this is not warranted and considered as wear and tear through use of the item.

all terms outlined in this document are applicable exclusively to projects and orders that are based in australia.

for warranty claims outside australia, please note that a 12 month warranty period will apply, all claims are to be taken up with the international selling agent

to view the full warranty please refer to the link below <u>https://graziaandco.com.au/grazia-terms-and-conditions/</u>

craftmanship:	manufactured in australia
materials:	solid timber and veneer with stain finish
lead time:	if not in stock, 12-14 weeks
suitability:	indoor use





finishes & product care

solid timber and veneer

grazia&co timber furniture is finished with a clear satin lacquer inclusive of an ultraviolet light protector. this may reduce the harsh effects of direct sunlight although cannot eliminate fading and discolouration completely. therefore, we do not recommend furniture be left in direct sunlight for long periods of time. avoid placing hot crockery on furniture surfaces which in turn may burn, discolour or lift binding agents. coasters, clothes and mats can be placed between the surface and the hot object. do not position furniture over or next to heating or electrical appliances. please ensure furniture is not exposed to excessive quantities of liquids or moisture which may absorb into the timber. this may result in movements of the timber, change in form, cracking or mould. if your furniture is being used as a writing surface, grazia&co recommends blotters or pads to prevent ball point pens leaving imprints in the timber top. objects resting against or on top of furniture should have some form of padding between the timber and the object. avoid bare metal or sharp pointed edges. a small amount of natural movement of the timber is expected as it adapts to the conditions of your home, due to variations in humidity and temperature.



