
grazia&co melbourne 1 / 10-14 advantage road highett, vic, 3190 phone +61 3 9555 5760 grazia&co sydney 12b, 32 ralph street alexandria, nsw, 2015 phone +61 2 8914 0350

studio range



designed by Christopher Elliott for grazia&co and released in 2023, the studio range consists of a set of timber drawers and side tables featuring rounded edges to the profiles and brass detailing on the handles. available in a range of timber stains.



timber




side table tray insert







technical specifications


1 - side table





2 - chest of drawers





product specifications

year released 2023

registration studio side table 202310846

studio chest of drawers 202311880

warranty

i. warranty period of 2 years for the structural integrity of the furniture under "normal use"

ii. natural materials like solid and veneer timbers can vary in colour, natural figuration and texture. these are not considered faults.

iii. movement, joint separation, bowing as a result of fluctuations in temperature and any damage caused by direct sunlight are not warranted.

iv. day to day use and wear and tear that can cause scratches, expansion, colour changes, chips, burns, splits are not warranted.

v. painted and stained timber can chip. this is not warranted and considered as wear and tear through use of the item.

to view the full warranty please refer to the link below https://graziaandco.com.au/grazia-terms-and-conditions/

craftmanship: manufactured in australia

materials: combination of solid and timber veneer in

specified finish, brass.

fabric tray liner (side table only)

lead time: 8-10 weeks. lead times may vary during

peak periods

suitability: indoor

australian made

2 year warrant



finishes & product care

solid timber and veneer

grazia&co timber furniture is finished with a clear satin lacquer inclusive of an ultraviolet light protector. this may reduce the harsh effects of direct sunlight although cannot eliminate fading and discolouration completely. therefore, we do not recommend furniture be left in direct sunlight for long periods of time. avoid placing hot crockery on furniture surfaces which in turn may burn, discolour or lift binding agents. coasters, clothes and mats can be placed between the surface and the hot object. do not position furniture over or next to heating or electrical appliances. please ensure furniture is not exposed to excessive quantities of liquids or moisture which may absorb into the timber. this may result in movements of the timber, change in form, cracking or mould. if your furniture is being used as a writing surface, grazia&co recommends blotters or pads to prevent ball point pens leaving imprints in the timber top. objects resting against or on top of furniture should have some form of padding between the timber and the object. avoid bare metal or sharp pointed edges. a small amount of natural movement of the timber is expected as it adapts to the conditions of your home, due to variations in humidity and temperature.

please visit grazia&co website for further details.

